











Anziehvorschrift für Zylinderkopf		194.728	
Tightening Instructions for Cylinder Head		passend für / fitting on	
Instructions de serrage pour culasse		adaptable a / adaptable a	
Prescripciones de apriete para culatas		Fiat	
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete:			
<div><div>⑧⑥②⑤⑩</div><div>⑦③①④⑨</div></div>			
Anziehen:	124.C1	131.B1.000	132.D.000
Tightening:		131.B2.000	
Serrage:		132.C.000	
Apriete:		132.C2.000	
	40 Nm		 40 Nm
	77 Nm		 90°
			 90°
Zeichenerklärung / Explanations / Explication / Explicacion:			
 neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplear tornillos nuevos
 Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
 Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	desserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
 Setzzeit	relaxation time	durée de tassement	tiempo de relajación
 Drehwinkel	torque angle	angle de serrage	ángulo de giro